

Virtual Transport 2 - VCube not detected

Problem

Pyramix and Vcube are installed on the same computer, but VCube is not detected in Virtual Transport 2.

Solution

Your computer need to have a valid network (IP adress), so Bonjour can detect VCube and show it in Virtual Transport 2 window.

If you don't want or can't have a valid network on your computer, you may create a virtual network card.

1. Please go in Windows Control Panel > Device Manager.
2. Right click on the computer name at the top of the device tree, and select Add legacy hardware.
3. Click on Next to continue, and select "Install the hardware that I manually select from a list (Advanced)".
4. Select Network Adapters
5. Browse to Manufacturer : Microsoft ; and select Microsoft Loopback adapter.

Now you can restart the computer. A new network device will now allow this PyraCube configuration to work.