

# HOW TO Guides

- Configuration
  - Connecting an external audio device to MERGING+NADAC
  - Install the MERGING+NADAC ASIO driver on Windows
  - Install the MERGING+NADAC CoreAudio driver on MacOS
  - MERGING+NADAC DC power input
- Integrate MERGING+NADAC in your home network
  - Network Connections
    - Configure the Network Firewall for your MERGING+NADAC favorite application
    - Configure your Antivirus for your MERGING+NADAC and your favorite application
    - IP Networks range
    - Setting an IP address manually
    - Setting Automatic IP addresses on your computer
- Integrate MERGING+PLAYER in your home network
- Listen to Windows audio with MERGING+NADAC using JRIVER WDM Driver.
- Media Players configuration
  - Configure AcourateConvolver with MERGING+NADAC on Windows
  - Configure AUDIRVANA Plus with MERGING+NADAC on MacOS
  - Configure EMOTION with MERGING+NADAC on Windows
  - Configure iTunes with MERGING+NADAC on Mac OS
  - Configure JRIVER with MERGING+NADAC on MacOS
  - Configure JRIVER with MERGING+NADAC on Windows
  - Configure ROON Labs with MERGING+NADAC on MacOS
  - Configure ROON Labs with MERGING+NADAC on Windows
  - Configure ROON Labs with NADAC PLAYER
    - Roon Channel mapping
  - Configure Signalyst HQPlayer for Windows
  - Configure Signalyst HQPlayer on MacOS
  - How to play in Emotion, on different zones, different playlists with different sampling rate ?
  - Roon DSP Engine recommendations.
- MERGING+PLAYER Updating Roon.
- MERGING+POWER Quick Start
- NADAC & NADAC PLAYER Maintenance mode update.
- NADAC Firmware Update Procedure
- NADAC PLAYER Firmware Update Procedure
- Remote control of your MERGING+NADAC