

HOW TO Guides

- Configuration
 - Connecting an external audio device to MERGING+NADAC
 - Install the MERGING+NADAC ASIO driver on Windows
 - Install the MERGING+NADAC CoreAudio driver on MacOS
 - MERGING+NADAC DC power input
- Integrate MERGING+NADAC in your home network
 - Network Connections
 - Configure the Network Firewall for your MERGING+NADAC favorite application
 - Configure your Antivirus for your MERGING+NADAC and your favorite application
 - IP Networks range
 - Setting an IP address manually
 - Setting Automatic IP addresses on your computer
- Integrate MERGING+PLAYER in your home network
- Listen to Windows audio with MERGING+NADAC using JRIVER WDM Driver.
- Media Players configuration
 - Configure AcourateConvolver with MERGING+NADAC on Windows
 - Configure AUDIRVANA Plus with MERGING+NADAC on MacOS
 - Configure EMOTION with MERGING+NADAC on Windows
 - Configure iTunes with MERGING+NADAC on Mac OS
 - Configure JRIVER with MERGING+NADAC on MacOS
 - Configure JRIVER with MERGING+NADAC on Windows
 - Configure ROON Labs with MERGING+NADAC on MacOS
 - Configure ROON Labs with MERGING+NADAC on Windows
 - Configure ROON Labs with NADAC PLAYER
 - Roon Channel mapping
 - Configure Signalyst HQPlayer for Windows
 - Configure Signalyst HQPlayer on MacOS
 - How to play in Emotion, on different zones, different playlists with different sampling rate ?
 - Roon DSP Engine recommendations.
- MERGING+PLAYER Updating Roon.
- MERGING+POWER Quick Start
- NADAC & NADAC PLAYER Maintenance mode update.
- NADAC Firmware Update Procedure
- NADAC PLAYER Firmware Update Procedure
- Remote control of your MERGING+NADAC